


WIRING DIAGRAM

MODEL : PRIMA PRO CONVECTION OVEN - 230V
MODEL CODE : COA1004

LEGEND	DESCRIPTION	PART NUMBER
S	STAGE SWITCH	1 - SEL - SWITCH
L	INTERIOR LIGHT	1 - OVEN - LH
F1 / F2	FANS	1 - FAN - COA1003
T	TIMER	1 - 2HR - TIMER
B1	BAKE THERMOSTAT	1 - EGO - 150
H1	TIMER PILOT LIGHT	1 - PL - GP
H2	BAKE PILOT LIGHT	1 - PL - GP
E1 / E2	BAKE ELEMENTS 1200W / 230V	5 - 1200W - CAT - BAK
E3	GRILL ELEMENT 2400W / 230V	5 - 2400W - CAT - GRI
B2	GRILL THERMOSTAT	1 - EGO - 150
H3	GRILL PILOT LIGHT	1 - PL - GP



Model COA 1005 / COA1005-ICE only –

Set the BAKE CONTROL to the desired temperature. Set the TIMER CONTROL to the desired time. The fans and the oven light will operate continuously, however the elements will switch off at the end of the timed cycle. The pilot light will indicate when the heating elements are energised. The desired temperature is reached when the pilot light starts to switch on and off. The oven is fitted with reversing fan motors which operate independently on a 4 minute timed cycle

The COA1005 Oven has a green push button that activates a spray of water, which creates humidity inside the oven chamber. This feature is used when a crisp outer layer is required on such products such as bread rolls. Humidity should only be injected in 2-second pulses after the oven has reached operating temperature and the product has just been placed inside i.e. at the beginning of the baking cycle.

SAFETY INSTRUCTIONS:

1. READ ALL INSTRUCTIONS BEFORE USE.
2. Do not touch hot surfaces!!! Always use hot pad or holder until unit cools.
3. To protect against electrical hazards, do not immerse cord, plug, or oven in water or any other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner.
6. Do not use outdoors.
7. Do not let cord hang over edge of table or counter or touch hot surfaces.
8. Do not place on or near a hot gas or electric burner.
9. Extreme caution must be exercised when disposing of hot grease.
10. Do not clean with metal scouring pads as metal particles can break off the pad and touch electrical parts, creating a potential shock hazard.
11. A fire may occur if this appliance is covered, or if flammable material touches against it.
12. Extreme caution should be exercised when using containers other than the intended proper heat tempered metal and glass pans for baking.
13. Do not cover any part of the oven or a sheet pan used as a drip tray with aluminium foil as this may cause overheating of the oven.
14. These countertop ovens are designed to operate on alternating current only (A.C.).