

WARNING!

RUN BEFORE FIRST USE VACUUM SENSOR CALIBRATION

In order to adjust the sensor to the altitude detection, at the first use and any time the machine is moved from a place to another at a different altitude, it's necessary to operate the vacuum sensor calibration. To do it, it's necessary to keep the VAC key pressed while turning the machine on, after 2 seconds release the VAC Key and close the lid.

