


RESET OIL ALARM



Press VAC(A) + START(D) and switch ON the machine at the same time and release the touch keys after 3 seconds.

Reset the counting pressing STOP for 3 sec.
(the 4 LED 1,2,3,4 will flash follow by acoustic signals)